

3/17

121




FIG. 3




FIG. 4

5/17




FIG. 5




FIG. 6




FIG. 7




FIG. 8

9/17

500




FIG. 9




FIG. 10




FIG. 11




FIG. 12




FIG. 13




FIG. 14




FIG. 15




FIG. 17

SELECTIONS FROM
MENU OR SCREEN

QUICK TIP: PRESS
ANIMATION TO HEAR AND
SEE DEMO

ANIMATION

VOICE

FIG. 18

MORE INFORMATION

USER ICON

AUDIO SYSTEM RADIO CASSETTE CD VIDEO TV WEATHER BAND

RADIO STATIONS: XX LOS ANGELES, XX SANTA ANA STATIONS
X IRVINE
SAVE AREA SETTINGS YES NO

SELECTION BEING PLAYED:
XX SONG, XX ALBUM 1245

WEATHER BAND
OTHER

YOU ARE
LISTENING
TO:

1273
10 COUNTRY: FM100.7

1275
8 TALK/NEWS: AM79.00 FM89.9 FM91.2 AM98.6 AM10.70

5 ROCK: FM89.3 FM98.1

2 CLASSIC: FM91.4 FM96.4

AM990 FM102.7 FM107.90
1277

SET FOR: DRIVER PASSENGER 1 2 3 4 5

ON OFF VOLUME CONTROL BASS TREBLE

FADER CONTROLS FRONT LEFT RIGHT
BACK LEFT RIGHT

MOVE SPEAKERS FOR
DESIRED SOUND
EFFECTS

PRESS EFFECT THEN
SPEAKER
ROCK
SURROUND
MOVIE
ETC.

1251 1255 1257

YOU
ARE
HERE

QUICK TIP: SCROLL FOR
XX MORE STATIONS
USE MOUSE CONTROLS
OR PRESS TO SELECT

QUICK TIP: ANTENNA
IS ACTIVATED BY
RADIO AND TELEPHONE,
BOTH MUST BE
SWITCHED OFF TO
LOWER ANTENNA

STEREO

DOLBY

DIGITAL
ENCODED

SMART AUDIO

AUTO RADIO

RESTORE SETTINGS

MORE INFORMATION

SAVE PREFERENCES

1207

1205